## FLEXICIAD ER

## Revolutionary Elastomeric Polymer Composite Repairs, Resurfaces & Protects Flexible Components.

FLEXICLAD® ER is a two component, 100% solids, trowelable polymer composite that has been specifically formulated to repair damaged flexible components such as conveyor belts, hoses, off-road tire sidewalls, etc.

FLEXICLAD® ER is a very unique material that requires no primer, bonds to most rubber / flexible materials and cures at ambient temperatures – no heat is required. It is safe and simple to use and no special tools are needed. It can be used to create irregular flexible gaskets on distorted flange faces or to create a resilient bond for metal, wood, etc. It can also be used to seal / caulk heat exchanger water boxes to tube sheet faces or to seal joints in condensate pans, cooling tower pans, etc. FLEXICLAD® ER is an indispensable addition to any maintenance engineer's tool box.

FLEXICLAD® ER is ideal for sealing joints and seams on machinery and equipment that are prone to vibration or movement – and wherever flexible repairs are required:

- Conveyor Belts
- Hoses
- Damaged Sidewalls On Off Road Tires
- Resilient Bonding of Metals, Woods, etc.
- Creating / Repairing Flexible Seals, Gaskets & Seats
- Expansion Bellows

















Toll Free: 888-4-ENECON (888-436-3266)

Tel: 516 349 0022 · Fax: 516 349 5522 Email: info@enecon.com

6 Platinum Court · Medford, NY 11763-2251

Technical Data					
Volume capacity: 250 g unit		14.1 in <sup>3</sup> / 233 cm <sup>3</sup>			
Mixed density		0.039 lbs / in <sup>3</sup> (1.07 gm / cc)			
Coverage rate @ 1/8 inch:					
250 g	unit	113 in <sup>2</sup> / 730 cm <sup>2</sup>			
Shelf life		Indefinite			
Volume solids		100%			
Mixing ratio	Base	Activator			
By volume	2	1			
By weight	1.7	1			

Working	Life	& Cure	Times		
Amb	ient	Working	Return to	Full	
Tempe	rature	Life	Service	Cure	
41°F	5°C	50 min	8 hrs	5 days	
59°F	15°C	30 min	6 hrs	4 days	
77°F	25°C	16 min	3 hrs	3 days	
86°F	30°C	12 min	45 min	36 hrs	

Physical Properties					
	Typical	Values	Test Method		
Hardness - Shore D	15		ASTM D-2240		
Tensile Shear Adhesion					
Steel	500 psi	35 kg/cm <sup>2</sup>	ASTM D-1002		
Copper	500 psi	35 kg/cm <sup>2</sup>	ASTM D-1002		
Both cases exhibited cohesive failure in the FLEXICLAD® ER itself.					
Note: Adhesion to most rubber substrates when properly prepared is greater than the cohesive strength of the rubber substrate.					

<b>Chemical Resistance</b>				
Acetic acid (0-10%)	Nitric acid (0-10%). G Phosphoric acid (0-5%) EX Phosphoric acid (5-10%) G Potassium chloride EX Propyl alcohol G Sodium chloride EX Sodium hydroxide EX Sulfuric acid (0-10%) EX Sulfuric acid (10-20%) G			
<ul><li>EX - Suitable for most applications including immersion.</li><li>G - Suitable for intermittent contact, splashes, etc.</li></ul>				



## Using FLEXICLAD ER

**Surface Preparation -** FLEXICLAD® ER should only be applied to clean, dry and well roughened surfaces.

- 1. Remove all loose material and surface contamination and clean with a suitable solvent which leaves no residue on the surface after evaporation such as acetone, MEK, isopropyl alcohol, etc.
- 2. Clean / roughen surface by appropriate means. Rigid surfaces (metal, concrete, etc.) should be prepared by grit blasting for large areas and unusual shapes or using a grinder, needle gun, etc. for more localized areas. Rubber substrates should be roughened by wire brushing, sanding, etc.
- 3 . Remove any and all loose dust / debris after roughening the surface.

Mixing & Application - For your convenience, the FLEXICLAD® ER Base and Activator have been supplied in precisely measured quantities. Simply pour the entire contents of the Activator container into the Base container and, using a spatula, putty knife or other appropriate tool, mix thoroughly until the FLEXICLAD® ER reaches a uniform streak-free black color. Apply the mixed material to the prepared surface using a stiff-bristled brush or flexible applicator.

Health & Safety - Every effort is made to insure that ENECON® products are as simple and safe to use as possible. Normal industry standards and practices for housekeeping, cleanliness and personal protection should be observed. Please refer to the detailed MATERIAL SAFETY DATA SHEETS (MSDS) supplied with the material (also available on request) for more information.

**Cleaning Equipment -** Wipe excess material from tools immediately. Use acetone, MEK, isopropyl alcohol or similar solvent as needed.

**Technical Support** - The ENECON® engineering team is always available to provide technical support and assistance. For guidance on difficult application procedures or for answers to simple questions, call your local ENECON® Fluid Flow Systems Specialist or the ENECON® Engineering Center.

All information contained herein is based on long term testing in our laboratories as well as practical field experience and is believed to be reliable and accurate. No condition or warranty is given covering the results from use of our products in any particular case, whether the purpose is disclosed or not, and we cannot accept liability if the desired results are not obtained.

Copyright © 2012 by ENECON® Corporation. All rights reserved. No part of this work may be reproduced or used in any form or by any means - graphic, electronic or mechanical including photocopying, recording, taping or information storage and retrieval systems - without written permission of ENECON® Corporation.